

Photocatalysis LED Arrays



USB 2.0
Control via GUI

Device: Lumidox®II Controller

Function: Controls Lumidox II LED arrays and LumpLamp

Hardware:

- USB

API / SDK:

- lumgen2_serial_commands_oem_rev1a.pdf
- lumidox_II_console_interface_rev1b.zip
- lumidox_II_fast_pulse_rev1a.zip


Firmware Update

- LumidoxII Firmware v1.28 Release.zip

Download from: <https://www.analytical-sales.com/product/lumidox-gen2-led-controller/> (Additional Information tab)

Column Temperature Control

MonoSLEEVE™



USB 2.0
Control via GUI

External Contacts

Device: MonoSleeve™ Controller

Function: Single Column Heater

Hardware:

- Contact closures
- USB

Software:

- GUI Software: [ASALE528.exe](#)
- Windows 10 USB Drivers for MonoSleeve and MultiSleeve: [CDM v2.12.28 WHQL Certified.zip](#)

Download from: <https://www.analytical-sales.com/product/monosleeve-single-column-heater-controller-monosleeve/> (Additional Information tab)

Column Temperature Control

MultiSLEEVE™



External Contacts

USB 2.0 Control via GUI

Device: MultiSleeve™ Controller

Function: 4 Channel Column Heater

Hardware:

- Contact closures
- USB


Software:

- GUI Software: [MULTISLEEVE.exe](#)
- Windows 10 USB Drivers for MonoSleeve and MultiSleeve: [CDM v2.12.28 WHQL Certified.zip](#)

Download from: <https://www.analytical-sales.com/product/multisleeve-4-port-temperature-control-unit-multisleeve/> (Additional Information tab)

Column Temperature Control

COLD SLEEVE™
Column Cooler/Heater



RS232 Control

External Contacts

Device: Cold Sleeve™ Controller

Function: Column Cooler/Heater

Hardware:

- Contact closures
- RS232 control

Software:

- GUI Software: [5R7520.exe](#)

Download from: <https://www.analytical-sales.com/product/cold-sleeve-column-cooler-heater-cold-sleeve-30/> (Additional Information tab)